# POLYCOM® CCX 600
# BUSINESS MEDIA PHONE
## Set Up Guide



## PACKAGE CONTENTS

| With Handset Cradle | Handset | Handset Cord | | Without Handset Cradle |
|---|---|---|---|---|



| Network Cable | Setup Sheet |
|---|---|

## OPTIONAL ACCESSORIES

**AC power adapter**
(varies by region)

**Wallmount**

**CCX Video Stand**

**Polycom EagleEye Mini USB Camera**

For more information on optional accessories, contact your reseller.

## FEATURES

Reversible Tab
(secures the phone
at high angles)

Screen

Message Waiting
Indicator

Application Command*

Volume Up

Volume Down

USB ports (on side)

Headset**

Speakerphone**

Speaker

Mute

*Icon displays only when the phone is powered on and the feature is
available. Icon may vary (        |        ).
**Icon displays when the phone is powered on.

# CONNECT CABLES

Optional: Ethernet connection to computer

Cable Groove
(Press straight part
of cable into groove)

AC power connection (optional accessory)
Use if Power over Ethernet (POE) is unavailable.

Note: Use only the power supply designed for your phone to avoid damaging the phone.

For proper cord management, put cables through the slot in the stand before connecting cables to the phone.

# CONNECT DESKTOP STAND

55° - 70°

55°

70°

# CONNECT OPTIONAL HEADSET

USB port (on side) →

EHS port
RJ-9 port

Your phone supports USB and wired headsets, including Electronic Hook Switch (EHS) headsets. For connection directions, refer to your headset documentation. Standard headsets use the RJ-9 or USB port while EHS headsets typically use the RJ-9 and EHS ports.

For more information, visit **epb.com/customer-support/business-support** or call **423-648-1500**, option 2

**epb** Fiber Optics